

Step 3

Insert the M-CARD obtained from your cable provider



Optional SDV


If your provider uses SDV, connect the tuning adapter to the USB port on the HDHomeRun PRIME and the cable line

USB is not for use with external hard drive or other devices.



Step 4

Connect the power adapter to the **HDHomeRun PRIME** and an outlet



Step 5

Go to My.HDHomeRun.com and follow instructions for setting up your HDHomeRun PRIME and follow the Set Up Wizard



Step 6

Contact your cable provider to set-up the CableCARD. Enjoy watching across the largest number of Media devices and software programs of any other product

